

---

## Documentation Author

F.Lambercy and J.Tharin for K-Team S.A.  
chemin des Plans-Praz  
CH-1337 Vallorbe  
Switzerland

email: [info@k-team.com](mailto:info@k-team.com)

Url: [www.k-team.com](http://www.k-team.com)

## Documentation Version

- 3.4: 04.04.2012 J. Tharin: USB link not working
- 3.3: 29.03.2012 J. Tharin: added Matlab instructions, kh3 server, corrected errors
- 3.2: 15.12.2011 J. Tharin: added khepera3 C functions documentation
- 1.0: 01.09.2006 F.Lambercy and G.Caprari: first version

## TRADEMARK ACKNOWLEDGMENTS:

**Matlab:** MathWorks Corp.

**IBM PC:** International Business Machine Corp.

**Khepera:** K-Team and LAMI

## LEGAL NOTICE:

- The content of this manual is subject to change without notice.
- All effort have been made to ensure the accuracy of the content of this manual. However, should any error be detected, please inform K-Team S.A.
- The above notwithstanding K-Team can assume no responsibility for any error in this manual.

# TABLE OF CONTENTS



<b>1</b>	<b>Introduction</b>	<b>4</b>
1.1	How to Use this Manual . . . . .	4
1.2	Safety Precaution . . . . .	4
1.3	Recycling . . . . .	5
<b>2</b>	<b>Unpacking and Inspection</b>	<b>6</b>
<b>3</b>	<b>The Robot and Its Accessories</b>	<b>7</b>
3.1	The Khepera III Robot . . . . .	7
3.1.1	Overview . . . . .	7
3.1.2	ON-OFF Battery Switch . . . . .	8
3.1.3	Indication LEDs . . . . .	8
3.1.4	Serial connector . . . . .	9
3.1.5	Cable unroller connector . . . . .	10
3.1.6	USB connector . . . . .	10
3.1.7	How to plug a KoreBot II . . . . .	11
3.2	Motors and motor control . . . . .	12
3.2.1	KheperaIII with a firmware 3.0 or greater . . . . .	12
3.2.2	KheperaIII with an older firmware . . . . .	12
3.2.3	Speed . . . . .	15
3.3	Infra-red Proximity sensors . . . . .	18
3.3.1	Ambient light measurements . . . . .	19
3.3.2	Reflected light measurements (proximity) . . . . .	19
3.4	Ultrasonic sensors . . . . .	20
3.5	Battery . . . . .	21
3.6	Power Supply . . . . .	21
<b>4</b>	<b>Connections</b>	<b>22</b>
4.1	Configuration for batteries charge . . . . .	22
4.2	Configuration for Communication in standalone . . . . .	23
4.3	Configuration for Communication in slave mode with KoreBot II	24
4.3.1	Serial link . . . . .	24
4.3.2	USB link . . . . .	25
4.4	Bluetooth Communication . . . . .	26
4.4.1	Bluetooth communication with KheperaIII . . . . .	26
4.4.2	Bluetooth communication with KoreBot II . . . . .	27
4.4.3	Log On the KoreBot II with a Bluetooth connection . . . . .	27
4.4.4	Khepera3 server . . . . .	27
4.4.5	Bluetooth communication on Linux . . . . .	28

---

Table Of Contents

---

<b>5</b>	<b>Serial Communication Mode</b>	<b>31</b>
5.1	Testing the primary serial link . . . . .	31
5.2	Testing the secondary serial link . . . . .	32
5.3	Serial communication protocol . . . . .	33
5.3.1	Testing a simple interaction . . . . .	33
<b>6</b>	<b>Robot programming</b>	<b>35</b>
6.1	Matlab programing . . . . .	35
6.2	Example of source code . . . . .	36
6.3	Functions available . . . . .	42
6.3.1	kh3_init . . . . .	42
6.3.2	kh3_configure_os . . . . .	43
6.3.3	kh3_proximity_ir . . . . .	43
6.3.4	kh3_ambient_ir . . . . .	44
6.3.5	kh3_battery_voltage . . . . .	45
6.3.6	kh3_reset_tstamp . . . . .	45
6.3.7	kh3_revision . . . . .	46
6.3.8	kh3_measure_us . . . . .	46
6.3.9	kh3_getcommand . . . . .	47
6.3.10	kh3_sendcommand . . . . .	47
6.3.11	kmot_SetMode . . . . .	47
6.3.12	kmot_SetSampleTime . . . . .	48
6.3.13	kmot_SetMargin . . . . .	48
6.3.14	kmot_SetOptions . . . . .	48
6.3.15	kmot_ResetError . . . . .	49
6.3.16	kmot_SetBlockedTime . . . . .	49
6.3.17	kmot_ConfigurePID . . . . .	49
6.3.18	kmot_SetSpeedProfile . . . . .	50
6.3.19	kmot_SetPoint . . . . .	50
6.3.20	kmot_GetMeasure . . . . .	50
<b>A</b>	<b>Communication protocol</b>	<b>51</b>
<b>B</b>	<b>Warranty</b>	<b>59</b>



## 1.1 How to Use this Manual

This manual is introducing the Khepera III robot. For a quick start and overview of the robot's functions, please read chapter 1 to 4.

Refer to the following summary if a particular information is needed. If the manual does not cover a particular problem, many more technical documentation is available online from K-Team website (<http://www.k-team.com>) and especially a Frequently Asked Question document to solve most common problems and questions.

**Unpacking and Inspection:** Khepera's package description.

**The robot and its accessories:** Khepera Hardware overview and main functions and accessories description.

**Connections:** detailed cables connections for various usage.

**Serial Communication mode:** detailed description for the Serial communication mode between a computer and the robot.

## 1.2 Safety Precaution

### **Check the unit's operating voltage before operation.**

It must be identical with that of your local power supply. The operating voltage is indicated on the nameplate at the rear of the power supply.

All connections (including extension addition or disconnection) must be made when the robot and the interface are switched OFF. Otherwise damages can occur.

### **Switch OFF the robot if you will not use it for more than a day.**

Disconnect the power supply removing it from the wall socket.

### **Do not manually force any mechanical movement.**

Avoid to force, by any mechanical way, the movement of the wheels or any other part.

If you have any question or problem concerning the robot, please contact your local Khepera dealer.

### 1.3 Recycling

Think about the end of life of your robot! Parts of the robot can be recycled and it is important to do so. It is for instance important to keep batteries out of the solid waste stream. When you throw away a battery, it eventually ends up in a landfill or municipal incinerator. These batteries, which contain heavy metals, can contribute to the toxicity levels of landfills or incinerator ash. By recycling the batteries through recycling programs, you can help to create a cleaner and safer environment for generations to come. For those reasons please take care to the recycling of your robot at the end of its life cycle, for instance sending back the robot to the manufacturer or to your local dealer.

**Thanks for your contribution to a cleaner environment!**

## 2 UNPACKING AND INSPECTION

---



Open the bag and check each item in the box. You should have the following material.

1. Khepera III robot
2. KoreBot II ( not included in the Khepera III base package )
3. Power Supply with a primary plug
4. Battery Pack
5. Optional KoreConnect



### 3.1 The Khepera III Robot

#### 3.1.1 Overview




Figure 3.1: Overview of the Khepera III robot.

Make an external inspection of the robot. Note the location of the following parts:

1. Infrared sensors.
2. Ultrasonic sensors.
3. Main serial connector.
4. USB miniAB connector.
5. Power jack connector.
6. Reset.
7. On / Off.
8. Cable unroller connector.

### 3.1.2 ON-OFF Battery Switch

It allows the user to switch the robot ON or OFF. When ON, the robot is powered. The robot may even be powered without the battery pack using the external power supply connector. See figure 3.1 number 7.

### 3.1.3 Indication LEDs

The Khepera III has six indication LEDs, two for the battery charger, one for the Power ON, one for the state of the motors controller and two programmables by the end-user (see figure 3.2).

When the Motor controller state LED is on, one of the two motor controller is in error mode. This could append when a motor is blocked or a current limit is detected. In this case the controller must be reset by the dsPIC ('M' command in serial interface mode or call 'initKH3()' in a KoreBot II program).

For the battery charger, the red one indicates that charge is in progress and the green one signals when the charge is complete. If there's no battery pack when you plug an external power supply, the green one will turn on.

The led 5 and 6 can be set by the user with 'K' command. See annexe A Serial communication protocol.




Figure 3.2: LEDs of the Khepera III.

1. Motor Controllers state LED (red).
2. Power ON LED (green).
3. Charge completed LED (green).
4. Charge in progress LED (red).
5. Programmable LED (green).
6. Programmable LED (red).

### 3.1.4 Serial connector

The serial connector contains various serial lines. One serial line which is at TTL level (0V/+5V) is used to connect a personal computer to the Khepera III dsPIC (with a KoreConnect). Used only when there is no KoreBot II connected. Please see section 4.2.

There is another RS232 (-10V/+10V) used to communicate with the KoreBot II, ie to see the KoreBot II's boot message. Please see section 4.3.

It is also possible to use the USB link of the KoreConnect to communicate with the KoreBot II.

**The length of the serial cable should be limited to two meters for proper operation.**

- |                |           |
|----------------|-----------|
| 1. Korebot RXD | 7. USB D- |
| 2. Korebot TXD | 8. USB D+ |
| 3. dsPIC RXD   | 11. GND   |
| 4. dsPIC TXD   | 12. GND   |
| 6. VCC ( +5V ) |           |



Figure 3.3: Details of the Khepera III serial connector. Pin 5, 9 & 10 are not connected.

### 3.1.5 Cable unroller connector

The cable unroller connector is a serial and a power connector (see figure 3.4). You can supply your robot and communicate with the robot through it. This connector is useful if you want to supply your robot with an external power supply (+9V) and keep its mobility with a cable unroller. However, if you want to recharge your battery at the same time, it is mandatory to use the power jack connector.

- |              |        |
|--------------|--------|
| 1. VCC (+9V) | 4. GND |
| 2. dsPIC RXD | 5. GND |
| 3. dsPIC TXD | 6. GND |




Figure 3.4: Details of the cable unroller connector.

### 3.1.6 USB connector

The mini-USB connector is useful only when a KoreBot II is plugged in the Khepera III. You can connect directly your PC to the Khepera III with an ordinary mini-USB cable. To communicate with the KoreBot II through the USB connector, please refer to the documentation of the KoreBot II (found on the web site [www.k-team.com](http://www.k-team.com)).

### 3.1.7 How to plug a KoreBot II

The Khepera III has been designed to work together with a KoreBot II, but as it isn't mandatory, in the default pack there is no KoreBot II with the robot. You can buy it at the same time, in this case, the KoreBot II will be mounted into the robot. But if you buy it afterward, you must first unmount the upper body of the Khepera III, then plug the KoreBot II on the extension connectors (see figure 3.5). If you have any other extension (KoreIO, KoreSound, KoreVision, etc...), you must only remove the black metal plate, and plug your extension on the KoreBot II.




Figure 3.5: Details of the KoreBot II assembly.

## 3.2 Motors and motor control

Before reading this section, please look at the firmware version of your KheperaIII. Since the firmware version 3.0, the gear of the motors have changed.

### 3.2.1 KheperaIII with a firmware 3.0 or greater

Each wheel is moved by a DC motor coupled with the wheel through a 65.6:1 reduction. The motor itself having a 41:1 reduction and the gear box having a 1.6:1 reduction. The motor has its own embedded incremental encoder, placed on the motor axis, gives 16 pulses per revolution of the motor. This allows a resolution of 1049.6 per revolution of the wheel that corresponds to 82 pulses per ten millimeter of path of the robot (diameter of the wheel = 41mm, thus each revolution the robot make 128.8mm). By default, the robot is set in mode encoder resolution x4, in this case for each wheel revolution the controller motor make 4198 measures. The other encoder configuration mode is 2x (1382 measures/turn).

Reminder: 1 revolution = 128.8mm = 4198 measures.

### 3.2.2 KheperaIII with an older firmware

Each wheel is moved by a DC motor coupled with the wheel through a 43.2:1 reduction. The motor itself having a 27:1 reduction and the gear box having a 1.6:1 reduction. The motor has its own embedded incremental encoder, placed on the motor axis, gives 16 pulses per revolution of the motor. This allows a resolution of 691.2 per revolution of the wheel that corresponds to 54 pulses per ten millimeter of path of the robot (diameter of the wheel = 41mm, thus each revolution the robot make 128.8mm). By default, the robot is set in mode encoder resolution x4, in this case for each wheel revolution the controller motor make 2764 measures. The other encoder configuration mode is 2x (1382 measures/turn).

Reminder: 1 revolution = 128.8mm = 2764 measures.

Each motor is driven by its own motor controller implemented in a PIC18F4431. The PIC has direct control on the motor power through a double H bridge and can read the pulses of the incremental encoder.

The motor control block acts as slave devices on the I2C bus. When the KoreBot II is not connected to the Khepera III robot, the main robot CPU will turn itself into an I2C master. When the KoreBot II is connected, it becomes the I2C master.

Each motor controller switches its motor ON and OFF at a given frequency and during a given time. By this way, the motor reacts to the time average of the power supply, which can be modified by changing the period the motor is switched ON. This means that only the ratio between ON and OFF periods is modified, as illustrated in figure 3.6. This power control method is called "pulse width modulation" (PWM). The PWM value is defined as the time the motor is switched ON.




Figure 3.6: The "Pulse Width Modulation" (PWM) motor supply mode is based on a ratio between the ON time and the total time. The basic switching frequency is constant.

Each motor controller can perform the control of the speed or the position of the motor, setting the correct PWM value according to the real speed or position read on the incremental encoders.

Both DC motors can be controlled by a PID controller. Every term of this controller(Proportional, Integral, Derivative) is associated to a constant, setting the weight of the corresponding term:  $K_p$  for the proportional,  $K_i$  for the integral,  $K_d$  for the derivative.

The motor controller can be used in two control modes: the speed or position mode. The active control mode is set according to the kind of command received. If the controller receives a speed control command, it switches to the speed mode. If the controller receives a position control command, the control mode is automatically switched to the position mode. Different control parameters ( $K_p$ ,  $K_i$  and  $K_d$ ) can be set for each of the two control modes.

### 3.2.3 Speed

Used in speed mode, the controller has as input a speed value of the wheels, and controls the motor to keep this wheel speed.

The speed value is a division of a constant value by the time between encoder pulsations. In default mode (encoder resolution x4 and postscaler 1:4), a measure is made four times every pulse. Then each revolution of the wheel, 4198 measures are made (firmware 3.0 or greater), or 2764 measures (Old firmware). The constant value is defined by the maximum time multiplied by 256 (0xFFFF \* 256 = 16'776'960). This operation allows a better PID calculation for the lower speed.

$$MotorSpeed = \frac{16'776'960}{Timer5value}$$

To convert into a real time, use the following calculation (example for the old firmware) (this time is the delay between two measures):

$$Time = \frac{\frac{Timer5value}{Postscaler}}{\frac{f_{osc}/4}{Tmr5Prescaler}}$$

where  $f_{osc} = 20\text{MHz}$  and  $Tmr5Prescaler = 8$  (default).

To get the real speed in mm/s:

$$RealSpeed = \frac{WheelCircumference}{Time * 2764}$$

where WheelCircumference is 128.8mm and 2764 correspond to the number of measures per revolution of the wheel.

For the old firmware the one encoder unit corresponds to  $128.8/2764 = 0.047$  mm and for the new on :  $128.8/4198 = 0.031$  mm.

Here's an example with  $MotorSpeed = 20'000$ ,  $Tmr5Prescaler = 8$ ,  $Postscaler = 4$  and encoder resolution = x4

$$Timer5value = \frac{16'776'960}{20'000} = 839$$

$$Time = \frac{\frac{839}{4}}{\frac{20'000'000/4}{8}} = 0.336[ms]$$

$$RealSpeed = \frac{128.8}{0.000336 * 2764} = 138.9[mm/s]$$

$$RealSpeed = \frac{MotorSpeed}{Kspeed}[mm/s]$$

Where Kspeed is 144.01 when default configuration is used with the old firmware. For firmware 3.0 or greater, the Kspeed is 218.72.

### 3. The Robot and Its Accessories

---

The maximum reachable speed is 48'000 (= 333 mm/s old — 219 mm/s new) in open loop, and 43'000 (= 298 mm/s for old — 196 mms/s for new) in regulation mode. And the minimum is 2'000 (= 13.9 mm/s for old — 9 mm/s for new) with regulation control.

Used in position profile mode ('F' command), the controller has as input a target position of the wheel, an acceleration and a maximal speed. Using this values, the controller accelerates the wheel until the maximal speed is reached, and decelerates in order to reach the target position. This movement follows a trapezoidal speed profile, as described in figure 3.7.




Figure 3.7: Speed profile to reach a target position with a fixed acceleration (acc) and maximal speed (max speed).

The input values and the control mode of this controller can be changed at every moment. The controller will update and execute the new profile in the position mode, or control the wheel speed following the new value in the speed mode.

First configure the speed profile ('J' command) with the needed parameters. Then you can perform a move with the position profile mode ('F' command). See annexe A for more details about communication protocole.

### 3.3 Infra-red Proximity sensors

Khepera III has nine sensors placed around the robot and two placed on the bottom. The latter allow experiments like line following. They are positioned and numbered as shown in figure 3.8.




Figure 3.8: Bottom view of the IR sensors

These sensors embed an infra-red light emitter and a receiver. For detailed description, please refer to the manufacturer's datasheet. The eight sensors are TCRT5000, reflective optical sensors from *Vishay Telefunken*.

This sensor device allows two measures:

- The normal ambient light. This measure is made using only the receiver part of the device, without emitting light with the emitter. A new measurement is made every 33 ms. During the 33 ms, the eleven sensors are read in a sequential way every 3 ms. The value returned at a given time is the result of the last measurement made.
- The light reflected by obstacles (= proximity). This measure is made emitting light using the emitter part of the device. The returned value is the difference between the measurement made emitting light and the light measured without light emission (ambient light). A new measurement is made every 33 ms. During the 33 ms, the eleven sensors are read in a sequential way every 3 ms. The value returned at a given time is the result of the last measurement made.

### 3.3.1 Ambient light measurements

Ambient light measurement is strongly influenced by the robot's environment. Depending on the light source type, color, and distance, ambient light measurement profile might vary. **It is not recommended to use light source with large emission in the infrared range, as this could confuse the IR sensors.**

### 3.3.2 Reflected light measurements (proximity)

Sensors are mainly meant to detect obstacles around the Khepera. Measurements for reflected light depends on objects reflectivity and on ambient light conditions. Objects color, materials and surfaces do have an influence on the sensors response. Moreover, as any sensor, IR sensors are subject to environmental noise. For all these reasons, graphics below are given for information only and should not be considered as references.




Figure 3.9: Relative collector current vs distance

### 3.4 Ultrasonic sensors

In its base set, 5 sensors are placed around the robot and are positioned and numbered as shown in figure 3.10.

5 sensors are in fact 5 pairs of ultrasonic devices where each pair is composed of one transmitter and one receiver.

The ultrasonic sensor are powered by a 20 Vdc source. The nominal frequency of these transducers is 40kHz +/- 1kHz.

Parameters such as max number of echo, timeout and active sensors are parametrizable through a configuration api (See 'C' command in chapter A). By default, you have maximum 3 echos, sensor 3 (front) is active, timeout is set to see from 20cm to 4 meters.

The last parameter is if the upper body is mounted or not (default mounted). When the upper body is mounted, there's some noise because of inside rebound echo, which are deleted in software. In fact, you could improve the detection of the nearest obstacles (20cm to 40cm) removing the upper body.

Each measure return the number of founded echos, the distance in cm of each echo, the amplitude of each, and the time (time stamp) when the echo was seen.

The value returned by the command, is the white noise measured before than a Ultrasonic pulse was sent. Then the real amplitude of each echo will be its amplitude minus the white noise. See command 'G' in chapter A for more details about the ultrasonic command.

For more details about the ultrasonic sensor, please check at Midas component, the transceiver is 400ST100 and the receiver is a 400SR100.




Figure 3.10: Position of the 5 UltraSonic sensors.

### 3.5 Battery

The Khepera III is equipped with a battery pack composed of two Li-Ion Polymer element. This provides a 7.4V volt battery with a 1400 mAH capacity. Using its embedded power, the robot is able to run completely autonomously during more than four hours, running with a basic configuration. When additional equipment are used, the autonomy is reduced as Khepera's extensions as the KoreBot II rely on Khepera's batteries as a power source.

There is no specific power management system on the Khepera. When the batteries voltage falls under 6V, the battery cut himself the power supply to avoid a too important discharge of the cell. Users can implement their own software power management system to handle KoreBot II to shutdown properly before this case happend. See command 'V' in chapter A for more details about battery management.

**Do not short circuit the battery pins or put down the battery on a metallic surface. This will damage the battery pack itself.**

### 3.6 Power Supply

If an external power source is required or during batteries charge, power can be supplied through the power jack connector or through the micro-Match cable unroller connector. See section 4 for detailed description of connections.

**Use only the power supply deliver by K-Team. If you want to supply the Khepera III with another device, make sure that the Voltage is +9V and that the power supply can deliver 2A.**

**SAFETY PRECAUTION:** The power supply must be connected to the wall socket after all other connections are already made.



### 4.1 Configuration for batteries charge

To charge robot's batteries, make sure the following are correct:

- The power supply shall be connected to the robot.
- Warning: the robot battery may be charged with the robot ON or OFF. Be attentive that when the robot is ON, the charging time will be a bit longer.
- The power supply have to be connected on a wall plug.

There are three leds. A green led tells if the robot is powered or not. And two other leds are here if the robot is charging ( red led ON ) or if the charge is complete ( green led ON ).

During the charge, the red led is switched ON and the green led is switched OFF. The process is reversed at the end of the charging process. The charging time for an empty battery is about 180 minutes. At this moment the power supply can be unplugged. When charging, the battery can be as hot as 40 degrees.

## 4.2 Configuration for Communication in standalone

This configuration allows communicating between the robot and a host computer through a serial link. The host computer is linked to the interface module using a standard RS232 line, while the interface module converts RS232 signal into a TTL level signal to communicate with the robot.

To use the standalone serial communication mode, please make sure the following are correct:

- No KoreBot II is connected on the Khepera III.
- The robot battery is charged that means the power led is switched on.
- The robot must be connected to a KoreConnect module using the serial cable
- The KoreConnect should be connected to the host computer using a standard RS232 cable. in this mode, the cable has to be connected on the DB9 connector number 2 (see fig 4.1). You can easily purchase such a cable from your host computer dealer.
- Serial port configured as followed : 115200bps, 8 Data bits, 1 stop bit , no parity, no hardware control.




Figure 4.1: Connection when the robot is used without a KoreBot II.

## 4.3 Configuration for Communication in slave mode with KoreBot II

### 4.3.1 Serial link

This configuration allows communicating between the KoreBot II plugged on the robot and a host computer through a serial link. In this configuration it is not possible to communicate with the robot base itself as explained in the previous chapter. The host computer is linked to the interface module using a standard RS232 line. The adaptation RS232/TTL is made on the KoreBot II.

To use the serial communication mode, please make sure the following are correct:

- A KoreBot II is connected on the Khepera III.
- The charged Battery or a power supply is plugged, and the robot is turned ON .
- The robot must be connected to a KoreConnect module using the serial cable
- The KoreConnect should be connected to the host computer using a standard RS232 cable. in this mode, the cable has to be connected on the DB9 connector number 1 (see fig 4.2) You can easily purchase such a cable from your host computer dealer.
- Serial port configured as followed : 115200bps, 8 Data bits, 1 stop bit, no parity, no hardware control.




Figure 4.2: Connection when the robot is used with a KoreBot II.

### 4.3.2 USB link

**WARNING: Currently the USB slave mode is disabled (see KoreBot2 User's Manual chapter 3.2.2.2). Therefore the instruction below is not working!**

This configuration allows communicating between the KoreBot II plugged on the robot and a host computer through a USB link. There are two ways to connect the USB to the KoreBot II. With a KoreConnect and standard USB cable or with only a mini-USB cable.

For more information about the USB communication protocol with a KoreBot II, please refer to the KoreBot II documentation (found on web site <http://www.k-team.com>).

To use the USB communication mode, please make sure the following are correct:

- A KoreBot II is plugged on the Khepera III.
- The charged battery or a power supply is plugged, and the robot is turned ON .
- The robot must be connected to a KoreConnect module and then a USB cable or a mini-USB cable is plugged directly on the USB miniAB connector of the robot (see figure 3.1).
- The USB cable (standard or mini) should be connected to the host computer. These two type of cable can be easily purchased from any computer dealer.

## 4.4 Bluetooth Communication

A Bluetooth device is mount on every KheperaIII with the firmware 2.0 or bigger. The device is a WT12 from BlueGiga, has the I-Wrap license and is configured by AT command. The device is completely configured for a cable replacement for the KheperaIII. But can be used with the KoreBot II too when plugged on the KheperaIII. Then the bluetooth connection will be available via the serial port `/dev/ttyS1` of the KoreBot II. The configuration is the following:

- 115200bps data rate
- 8 data bits
- no parity
- one stop bit
- no hardware flow control
- connection securised (security code is: 0000)

### 4.4.1 Bluetooth communication with KheperaIII

Here a procedure as example to establish a Bluetooth communication between KheperaIII and a PC, and how to validate the connection with a terminal (example for WinXp). No KoreBot II must plugged on the KheperaIII for this case.

- First connect your Bluetooth dongle to your PC (if necessary).
- Check if your system recognize your dongle and then install the driver. If you have Bluetooth integrated in your laptop, just activate it.
- Verify that your connection is securised and that a COM port is reserved for the Bluetooth serial communication (Menu: Bluetooth-Advanced Configuration-Client Application)
- Check if your KheperaIII is correctly powered (Led green ON)
- Start a device research "View device in range"
- The KheperaIII must appear with a PDA logo and the name KHIII SerialNumber. The Serial Number is the same as the label on the bottom.
- Create a connection with the KheperaIII, your program will ask you for a security code then enter 0000.
- Your program assign a COM port to your device.
- Open a terminal with the assigned COM port and the correct configuration as above
- Try to read the IR sensor value (or another command see chapter A) to validate the communication
- Then you can use any other program which used a COM port (like Matlab) to remote control your KheperaIII

#### 4.4.2 Bluetooth communication with KoreBot II

The procedure will be the same as above but with a KoreBot II plugged on the KheperaIII.

- Create a Bluetooth a connection with the KheperaIII as explained above
- To validate the communication, connect a KoreConnect to the KoreBot II (see section 4.3)
- Log on the KoreBot II (login: root , password: (none, push RETURN key) )
- open a minicom on the KoreBot II: **minicom -s /dev/ttyS1**
- Configure your terminal as describe above and select the /dev/ttyS1 device.
- Now the KoreBot II can send/received information to/from the PC via Bluetooth.

#### 4.4.3 Log On the KoreBot II with a Bluetooth connection

There's a way to use the /dev/ttyS1 (Bluetooth serial Port) to log on the KoreBot II. To do this, you need to modify the inittab file in the directory /etc of the KoreBot II as following (modified by default if the KorebotII is shipped with a robot):

- Log on the KoreBot II with a KoreConnect (login: root , password: (none, push RETURN key))
- Open the /etc/inittab files with command: **vi /etc/inittab**
- In the end of the files, you will see this line:  
**S:2345:respawn:/sbin/getty 115200 ttyS0**
- Modify it to: **S0:2345:respawn:/sbin/getty 115200 ttyS0**
- And add this line below: **S1:2345:respawn:/sbin/getty 115200 ttyS1**
- Save and close the file. Then in the next restart, you will be able to log on your KoreBot II with Bluetooth.

**Warning: making an error in the file /etc/inittab may prevent the board booting; please modify carefully!**

#### 4.4.4 Khepera3 server

For running Khepera3 Interface:

[http://ftp.k-team.com/KheperaIII/applications/Interface\\_Khepera3\\_Setup\\_V1-1\\_port\\_com.zip](http://ftp.k-team.com/KheperaIII/applications/Interface_Khepera3_Setup_V1-1_port_com.zip)

or any other program responding to A-Z commands defined in chapter A, if the Korebot 2 installed, you must run the application **kh3server** on the

Korebot2.

Follow the instructions below to install, configure and run the server:

- Get the server from here:  
`http://ftp.k-team.com/KheperaIII/applications/kh3_server.tar.bz2`
- connect to the korebot2 mounted on your Khepera3
- edit the file `/etc/inittab` and comment line:  
**S1:2345:respawn:/sbin/getty 115200 ttyS1**  
by adding a comment char `#` in the beginning of the line.

**WARNING: The line may not be present if the Korebot was shipped alone! Don't comment any other line! Pay attention to comment the right line! Making any error in this file may prevent the board booting!**

- reboot your Khepera3 (command: **reboot** )
- configure your Bluetooth to connect to the Khepera3 as mentioned in chapter 4.4.1.
- copy `kh3server` to the Korebot 2
- make it executable with: **chmod +x kh3server**
- run it with: **./kh3server**
- connect Khepera3 interface (or any other program) and run A-Z commands as usual.
- to stop it, push CTRL and c keys.

### 4.4.5 Bluetooth communication on Linux

For using Bluetooth communication with the Khepera3 Linux (Ubuntu), follow the instructions below:

- Install the Linux package `lrzsz` containing communications programs:  
**sudo apt-get install lrzsz**
- If `Minicom` is not installed you have to install this package, install it with:  
**sudo apt-get install minicom**
- Install `blueman`, a Bluetooth manager for Linux:  
**sudo apt-get install blueman**
- A bluetooth icon is on the Ubuntu panel if your Bluetooth is on. Double-click on that icon to open the `Blueman` and search for a new

device. The robot will appear as KHIII ABCD, where ABCD is its serial number .

- Select the KHIII ABCD and push the key button (or right click and pair) with the access key: 0000 (four zeros). A key should be added at the left of KHIII ABCD icon.
- Right click on the paired KHIII ABCD, choose Setup, then "Serial Port".
- Run minicom with the command: **sudo minicom -o**
- Set its parameters with the sub-menu Serial port setup of the menu [configuration] (keys Ctrl-a + o to access it) as described in below. Push RETURN key to validate each time.

```
+-----+
| A - Serial Device : /dev/rfcomm0 |
| B - Lockfile Location : /var/lock |
| C - Callin Program : |
| D - Callout Program : |
| E - Bps/Par/Bits : 115200 8N1 |
| F - Hardware Flow Control : No |
| G - Software Flow Control : No |
| |
| Change which setting? |
+-----+
```

- Save the settings with the command Save setup as of the menu [configuration] (cf below) and choose **bluetooth** as configuration name. You will be able to run again the program and load this configuration with: **sudo minicom -o bluetooth**

Then exit the config.

```
+-----[configuration]-----+
| Filenames and paths |
| File transfer protocols |
| Serial port setup |
| Modem and dialing |
| Screen and keyboard |
| Save setup as dfl |
| Save setup as.. |
| Exit |
+-----+
```

- In the file /etc/inittab of the robot, check if the console on the Bluetooth port is configured correctly (the following line is present; see chapter 4.4.3),

**S1:2345:respawn:/sbin/getty 115200 ttyS1**

PAY ATTENTION to not make mistakes while modifying this file as it may prevent booting and you will have to reflash the Korebot!!

- Reboot the robot, if you modified this line.
- Reboot the robot again but by pushing the reset button under the robot. You should see these lines if it works:

```
OpenEmbedded Linux korebot2 ttyS1
```

```
Angstrom 2007.9-test-20090708 korebot2 ttyS1
```

```
korebot2 login:
```

⇒ You can connect to it.



### 5.1 Testing the primary serial link

Before any further operations, the serial link between the host computer and the robot should be tested. Please read the following instructions to test the serial communication mode:

- Make sure all connections are correct (see chapter 4 for details).
- The robot should be placed on a flat and safe surface. The battery switch must be OFF.
- A terminal emulator should be running on the host computer. Make sure the terminal is connected to the correct serial port. **The terminal configuration must be set to 115200 Baud, 8 bit, 1 start bit, 1 stop bit, no parity and no hardware control.**

When powered on, the robot should send a message (see fig 5.1) to the terminal emulator.

To test that the KheperaIII is able to receive command, try to send the B command to ask the Khepera for the operating system version and revision.

```
flambercy on koala46: /home/lambercy
File Edit View Terminal Tabs Help
Khepera3 OS (c) K-Team S.A. 2006 ver 1.3
Battery Pack Found : SN 01A000081F0
Front extension detected
Master OS mode (standalone)

I2C Has been initialised as a master
Right motor initialisation completed ver 5.2
Left motor initialisation completed ver 5.2
Serial Communication Protocol
B
b,1,3
█
```

Figure 5.1: Boot message of the Khepera III.


## 5.2 Testing the secondary serial link

As the robot is suited to be used with a KoreBot II it is important to test the serial link between the host computer and the KoreBot II itself.

- Make sure all connections are correct (see chapter 4 for details).
- The robot should be placed on a flat and safe surface. The battery switch must be OFF.
- A KoreBot II needs to be plugged on the appropriate socket.
- A terminal emulator should be running on the host computer. Make sure the terminal is connected to the correct serial port. **The terminal configuration must be set to 115200 Baud, 8 bit, 1 start bit, 1 stop bit, no parity and no hardware control.**

When powered on, the KoreBot II will send the normal Linux boot message to the terminal emulator (see fig 5.2).

If any of the serial link is not working properly it is then important to ensure that the serial communication settings has been configured correctly.



```
flamperc on koala46: /home/lamperc
File Edit View Terminal Tabs Help
.Flaboot - minimal Flash Booter
(c) 2002 - 2003 Stephane Magnenat & Julien Pilet
This program is GPL

s-bot rom, pre-release, serial #00000000

Now loading...
Now booting...
Uncompressing Linux..... do.
Linux version 2.4.19-kb11 (amaye@koala54) (gcc version 2.95.3 20010315 (re5
CPU: XScale-PXA255 revision 6
Machine: K-Team Robotic development board
Fixup korebot
Warning: bad configuration page, trying to continue
Memory clock: 99.53MHz (*27)
Run Mode clock: 99.53MHz (*1)
Turbo Mode clock: 99.53MHz (*1.0, inactive)
On node 0 totalpages: 16384
zone(0): 16384 pages.
zone(1): 0 pages.
zone(2): 0 pages.
Kernel command line: console=ttyS0,115200 mem=64M noinitrd rootfstype=jffs)
Calibrating delay loop... 99.12 BogoMIPS
Memory: 64MB = 64MB total
```

Figure 5.2: Boot message of the KoreBot II.

### 5.3 Serial communication protocol

When the robot is used as standalone ( without a KoreBot II ), the serial communication protocol is designed to control all Khepera's functions using a RS232 serial line. The serial line configuration (baudrate as well as data, start, stop and parity bits) for the host computer must match the robot's configuration.

The host computer and the Khepera robot are communicating with ASCII messages. Each single interaction is composed by:

- A command, beginning with one ASCII capital letters and followed, if necessary, by numerical or literal parameters separated by a comma and terminated by a carriage return or a line feed, sent by the host computer to the Khepera robot.
- A response, beginning with the same one ASCII letters of the command but in lower-case and followed, if necessary, by numerical or literal parameters separated by a comma and terminated by a carriage return and a line feed, sent by the Khepera to the host computer.

During the entire communication, the host computer is acting as a master and the Khepera as slave. All communications are initiated by the master.

Two different types of interactions are possible. The first set of interactions is used to set up the robot configuration from the host computer (set up serial line, changing controllers configuration,...), the second set of interactions is used to control the robot (controlling motors, reading sensors value,...).

A set of commands is available as detailed in appendix.

#### 5.3.1 Testing a simple interaction

Testing some basic commands is the best method to understand the serial protocol and tools available on the Khepera. Using a properly configured serial link between the robot and a computer, please follow the instructions bellow:

- Type the capital letter **B** followed by a carriage return or a line feed.
- The robot must respond with **b** followed by an indication of the version of software running on the robot and terminated by a line feed.
- Type the capital letter **N** followed by a carriage return or a line feed.
- The robot must respond with **n** followed by 11 numbers separated by a comma and terminated by a line feed. These numbers are the values of the robot proximity sensors presented in section 3.1.6.
- Retry the same command (N) putting some obstacles in front of the robot. The response must change.
- Type the protocol command **D,110000,1-10000** followed by a carriage return or a line feed.

## 5. Serial Communication Mode

---

- The robot must start turning on place and respond with **d** and a line feed.
- To stop the robot type the protocol command **D,10,10** followed by a carriage return or a line feed.
- Try other commands following the description given in Appendix A.

## 6 ROBOT PROGRAMMING

---



The robot cannot be directly programmed but you have to use an optional Korebot 2 board that can be plugged into the robot. See sections 6.2 and 6.3 below.

You can also use any software that can access the serial port like Matlab. See following section 6.1 for Matlab programming. The serial protocol is in Appendix A.

### 6.1 Matlab programing

The serial commands and protocol are explained in Appendix A. You can see below a small Matlab script example connecting to serial port COM5, getting robot version and US sensors data:

---

```
% configure serial port and open it
s = serial('COM5','BaudRate', 115200);
fopen(s);

% empty serial input buffer (Khepera3 boot message)
if s.BytesAvailable
    fread(s,s.BytesAvailable);
end

% get Khepera3 BIOS version and revision
fprintf(s,'B');
out = fscanf(s)

% should return: "b,VERSION,REVISION" where VERSION and REVISION are 2 numbers

% configure all US
fprintf(s,'C,0,d31');
out = fscanf(s)

% for 1 echo only:
fprintf(s,'C,1,d1');
out = fscanf(s)

% get data of US sensors
```



```
* \author    Julien Tharin (K-Team SA)
*
* \note      Copyright (C) 2012 K-TEAM SA
* \bug       none discovered.
* \todo      nothing.

* compile with command:
arm-angstrom-linux-gnueabi-gcc kh3test.c -o kh3test \
-I $INCPATH -L $LIBPATH -lkorebot

*/
#include <korebot/korebot.h>

static knet_dev_t * dsPic;
static knet_dev_t * mot1;
static knet_dev_t * mot2;

// motor position factor
#define PULSE_TO_MM_FIRMWARE_S_3 0.04629 // for version <3.0
#define PULSE_TO_MM_FIRMWARE_BE_3 0.03068

// motor speed factor
#define MM_S_TO_SPEED_FIRMWARE_S_3 144.01 // for version <3.0
#define MM_S_TO_SPEED_FIRMWARE_BE_3 218.72

// display bar length for sensor
#define IR_BAR_LEN 15

int main()
{

    float fpos;
    long lpos,rpos;
    char Buffer[100],bar[11][IR_BAR_LEN+5];
    int sensors[11],i,n,revision,version;
    short index, value;
    char usvalues[5];
    long motspeed;

    float pulsestomm=PULSE_TO_MM_FIRMWARE_S_3 ; // if version of the mot < 3.0
    float mmstospeed=MM_S_TO_SPEED_FIRMWARE_S_3 ; // if version of the mot < 3.0
```

```
kh3_init();

/* open various socket and store the handle in their respective pointers */
dsPic = knet_open( "Khepera3:dsPic" , KNET_BUS_I2C , 0 , NULL );
mot1 = knet_open( "Khepera3:mot1" , KNET_BUS_I2C , 0 , NULL );
mot2 = knet_open( "Khepera3:mot2" , KNET_BUS_I2C , 0 , NULL );

/* initialize the motor controller 1 */
kmot_SetMode( mot1 , kMotModeIdle );
kmot_SetSampleTime( mot1 , 1550 );
kmot_SetMargin( mot1 , 6 );
kmot_SetOptions( mot1 , 0x0 , kMotSWOptWindup | kMotSWOptStopMotorBlk
| kMotSWOptDirectionInv );
kmot_ResetError( mot1 );
kmot_SetBlockedTime( mot1 , 10);
kmot_ConfigurePID( mot1 , kMotRegSpeed , 620 , 3 , 10 );
kmot_ConfigurePID( mot1 ,kMotRegPos,600,20,30);
kmot_SetSpeedProfile(mot1 ,15000,30);

/* initialize the motor controller 2 */
kmot_SetMode( mot2 , kMotModeIdle );
kmot_SetSampleTime( mot2 , 1550 );
kmot_SetMargin( mot2 , 6 );
kmot_SetOptions( mot2 , 0x0 , kMotSWOptWindup | kMotSWOptStopMotorBlk );
kmot_ResetError( mot2 );
kmot_SetBlockedTime( mot2 , 10);
kmot_ConfigurePID( mot2 , kMotRegSpeed , 620 , 3 , 10 );
kmot_ConfigurePID( mot2 ,kMotRegPos,600,20,30);
kmot_SetSpeedProfile(mot2 ,15000,30);

// get revision
if(kh3_revision((char *)Buffer, dsPic)){

    version=(Buffer[1] | Buffer[2]<<8);
    revision=(Buffer[3] | Buffer[4]<<8);

    printf("\r\n%c,%4.4u,%4.4u => Version = %u, Revision = %u\r\n",
        Buffer[0],version ,revision,version ,revision);

    // change motor speed and position factor
    if (version <3)
    {
```

```
    pulsestomm=PULSE_TO_MM_FIRMWARE_S_3;
    mmstospeed=MM_S_TO_SPEED_FIRMWARE_S_3;
}
else
{
    pulsestomm=PULSE_TO_MM_FIRMWARE_BE_3;
    mmstospeed=MM_S_TO_SPEED_FIRMWARE_BE_3;
}

}

// get battery voltage
if(kh3_battery_voltage((char *)Buffer, 0, dsPic)){
    printf("\r\n%c,%3.3u,%3.3u => battery voltage = %u.%uV\r\n",
        Buffer[0], (Buffer[1] | Buffer[2]<<8), (Buffer[3] | Buffer[4]<<8),
        (Buffer[1] | Buffer[2]<<8), (Buffer[3] | Buffer[4]<<8));
}

/* For ever loop */
while(1)
{
/* Wait 2 seconds */
sleep(2);

// move forward

// read old encoder position
lpos = kmot_GetMeasure(mot1, kMotRegPos);
rpos = kmot_GetMeasure(mot2, kMotRegPos);

fpos = 20.0*10.0/pulsestomm;
printf("\nMoving forward %.1f cm in  %.1f pulses with position control\
(encoders: left %ld | right%ld)\n",20.0,fpos,lpos+(long)fpos,rpos+(long)fpos);

/* tell motor controllers to move K3 forward, using speed and accel profile */
kmot_SetPoint(mot1, kMotRegPosProfile, lpos+(long)fpos);
kmot_SetPoint(mot2, kMotRegPosProfile, rpos+(long)fpos);

/* Wait 5 seconds */
printf("\n wait 10s \n");
sleep(10);

/* Tell to the motor controller to move the Khepera III backward */
```

```

motspeed= (long)(-40.0*mmstospeed);
kmot_SetPoint( mot1 , kMotRegSpeed , motspeed );
kmot_SetPoint( mot2 , kMotRegSpeed , motspeed );

printf("\nMoving backward %.1f cm at %.1f mm/s (internal speed %d) with\
speed control\n",20.0,40.0,motspeed);

/* Wait 5 seconds */
sleep(5);

/* Tell to the motor controller to stop the Khepera III */
kmot_SetPoint( mot1 , kMotRegSpeed , 0 );
kmot_SetPoint( mot2 , kMotRegSpeed , 0 );

/* Wait 5 seconds */
sleep(5);

// get ir sensor
if(kh3_proximity_ir((char *)Buffer, dsPic))
{
    for (i=0;i<11;i++)
    {
        sensors[i]=(Buffer[i*2+1] | Buffer[i*2+2]<<8);

        n=(int)(sensors[i]/4096.0*IR_BAR_LEN);

        if (n==0)
            sprintf(bar[i],"\33[%dC>|",IR_BAR_LEN-1);
        else
            if (n>=IR_BAR_LEN-1)
                sprintf(bar[i],">\33[%dC|",IR_BAR_LEN-1);
            else
                sprintf(bar[i],"\33[%dC>\33[%dC|",IR_BAR_LEN-1-n,n);

    }
    printf("\n
                near                far\nback left    : %4.4u\
%s\nleft 90      : %4.4u  %s\nleft 45      : %4.4u  %s\nfront left  : %4.4u\
%s\nfront right : %4.4u  %s\nright 45     : %4.4u  %s\nright 90   : %4.4u\
%s\nback right  : %4.4u  %s\nback         : %4.4u  %s\nbottom right: %4.4u\
%s\nbottom left : %4.4u  %s\ntime stamp : %lu\r\n",
                sensors[0],bar[0], sensors[1],bar[1],
                sensors[2],bar[2], sensors[3],bar[3],

```

```
sensors[4],bar[4], sensors[5],bar[5],
sensors[6],bar[6], sensors[7],bar[7],
sensors[8], bar[8], sensors[9], bar[9],sensors[10], bar[10],
((Buffer[19] | Buffer[20]<<8) | (Buffer[21] | Buffer[22]<<8)<<16));
}

// configure us sensors
index=0;
value=31; // all us sensors active

if(kh3_configure_os((char *)Buffer, index, value, dsPic))
    printf("\r\n US sensors configured.\r\n");
else
    printf("\r\nconfigure OS error!\r\n");

// get and print us sensors
for (i=0;i<5;i++)
{

    if(kh3_measure_us((char *)Buffer, i+1, dsPic))
    {
usvalues[i] = (Buffer[0*8+3] | Buffer[0*8+4]<<8);
    }
    else
        printf("\r\nng, error...");
}

printf("US sensors : distance [cm]\nleft 90    : %3d\nleft 45    : %3d \
\nfront      : %3d\nright 45  : %3d\nright 90  : %3d\n",
        usvalues[0],usvalues[1],usvalues[2],usvalues[3],usvalues[4]);
} // while
}
```

---

This source code can be cross-compiled using *arm-angstrom-linux-gnueabi-gcc* which supports most standard *gcc* options. Open a terminal in your development folder as installed with the toolchain (see Korebot 2 User manual, chapter 4.2.2). Then run the following commands:

```
source env.sh
```

```
arm-angstrom-linux-gnueabi-gcc kh3test.c -o k3test
-I $INCPATH -L $LIBPATH -lkorebot
-L $LIBKOREBOT\_ROOT/build-korebot-2.6/lib -lkorebot
```

The last command with **arm-angstrom-linux-gnueabi-gcc** is in one line, ending with **-lkorebot**.

An **kh3test** executable file should be created, that can be executed on the KoreBot II, or eventually another arm-linux machine.

To execute the program, simply copy **kh3test** to the nfs shared directory, then execute it from a KoreBot II terminal. If the shared directory is mounted on the default */mnt/nfs*, first change working directory:

```
cd /mnt/nfs
```

Then check that kh3test is present:

```
ls -l
```

And execute it:

```
./k3test
```

### 6.3 Functions available

The functions available for the Khepera III are listed below. They are a subset of the **libkorebot** library. The whole API description can be found there:

<http://ftp.k-team.com/KorebotII/software/common/libkorebot/api/html/index.html>.

For the include files, you just to use this one: **#include <korebot/korebot.h>**.

Below the functions are described. The function names starting with **kh3\_** are coming from **kb\_khepera3.h** and the other starting with **kmot\_** are coming from **kmot.h** of the **korebot** library.

#### 6.3.1 kh3\_init

Call:           int kh3\_init (void)

Function:       initializes some things like the GPIO40 pin. This function needs to be called BEFORE any other functions.

Parameter:     none

Return:        <0 on error ; 0 on success

### 6.3.2 kh3\_configure\_os

Call: `int kh3_configure_os (char *outbuf, unsigned char index, unsigned char value, knet_dev_t *hDev)`

Function: configures the current firmware operation mode. a configuration array is used by the khepera3 to decide its mode of operation.

Parameters:

- outbuf is a buffer where the data will be stored on.
- index is the index pointing one of the configuration word in the config array. See paragraph "C Configure the current firmware operation" in Annexes for details.
- value is the value to store in the configuration array. See paragraph "C Configure the current firmware operation" in Annexes for details.
- hDev is a handle to an opened *knet* socket (Khepera3:dsPic).

Return:  $<0$  on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.3 kh3\_proximity\_ir

Call: `int kh3_proximity_ir (char *outbuf, knet_dev_t *hDev)`

Function: retrieves an instant IR measure.

Parameters:

- outbuf is a buffer where the data will be stored on. Where the  $sensor[i] = (outbuf[i * 2 + 1] | outbuf[i * 2 + 2] \ll 8)$  ;  $i$  is  $[0..10]$ , in the sensor order: back left, left 90, left 45, front left, front right, right 45, right 90, back right, back, ground right, ground left. A time stamp can be obtained with:  $((outbuf[19] \text{ --- } outbuf[20] \ll 8) \text{ --- } (outbuf[21] \text{ --- } outbuf[22] \ll 8) \ll 16)$ .
- hDev is a handle to an opened *knet* socket (Khepera3:dsPic).

Return:  $<0$  on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.4 kh3\_ambient\_ir

Call: int kh3\_ambient\_ir (char \*outbuf, knet\_dev\_t \*hDev)

Function: retrieves an instant IR measure.

Parameters:

- outbuf is a buffer where the data will be stored on. Where the  $sensor[i] = (outbuf[i * 2 + 1] | outbuf[i * 2 + 2] \ll 8)$  ; i is [0..10], in the sensor order: back left, left 90, left 45, front left, front right, right 45, right 90, back right, back, ground right, ground left. A time stamp can be obtained with:  $((outbuf[19] | outbuf[20] \ll 8) | (outbuf[21] | outbuf[22] \ll 8) \ll 16)$ .
- hDev is a handle to an opened knet socket (Khepera3:dsPic).

Return: <0 on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.5 kh3\_battery\_voltage

Call: int kh3\_battery\_voltage (char \*outbuf, unsigned char argument , knet\_dev\_t \*hDev )

Function: retrieves the actual battery voltage.

Parameters:

- outbuf is a buffer where the data will be stored on.
- argument parameter of the command:
  - 0: Read the voltage of the battery (Units: 1V , 0.1mV).
  - 1: Read the current of the battery (Units: 1A, 0.1mA).
  - 2: Read the battery Average Current (Units: 1A, 0.1mA).
  - 3: Read the battery Absolute Remaining Capacity (Units: 1mAh).
  - 4: Read the Temperature of the battery (Units: 1 C, 0.1 C).
  - 5: Read the battery Relative Remaining Capacity (Units: %).
- hDev is a handle to an opened knet socket (Khepera3:dsPic).

Return: <0 on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.6 kh3\_reset\_tstamp

Call: int kh3\_reset\_tstamp (char \*outbuf, knet\_dev\_t \*hDev)

Function: resets the absolute timestamp.

Parameters:

- outbuf is a buffer where the data will be stored on. in this case the only answer to expect is z, which is a ack.
- hDev is a handle to an opened knet socket (Khepera3:dsPic).

Return: <0 on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.7 kh3\_revision

Call: int kh3\_revision (char \*outbuf, knet\_dev\_t \*hDev)

Function: retrieves the current OS version/revision.

Parameters:

- outbuf is a buffer where the data will be stored on.
- hDev is a handle to an opened knet socket (Khepera3:dsPic).

Return: <0 on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.8 kh3\_measure\_us

Call: int kh3\_measure\_us(char \*outbuf, unsigned char usnbr, knet\_dev\_t \*hDev)

Function: retrieves measure from a given US transmitter.

Parameters:

- outbuf is a buffer where the data will be stored on.
- usnbr is a number of the us to read ( 1 to 5 ).
- hDev is a handle to an opened knet socket (Khepera3:dsPic).

Return: <0 on error,  $\geq 0$  on success (returns should be the size of frame).

Normally an end user don't want to use these two functions below as they are assumed as "low level functions":

### 6.3.9 kh3\_getcommand

Call: `int kh3_getcommand (knet_dev_t *hDev, unsigned char *out)`

Function: gets a command frame from a given khepera3 device.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- out is a pointer to a buffer where the command frame will be stored on.

Return:  $<0$  on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.10 kh3\_sendcommand

Call: `int kh3_sendcommand (knet_dev_t *hDev, unsigned char *in)`

Function: sets a command frame to a given khepera3 device.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- in is a pointer to a buffer where the command frame to be sent is stored on..

Return:  $<0$  on error,  $\geq 0$  on success (returns should be the size of frame).

### 6.3.11 kmot\_SetMode

Call: `void kmot_SetMode (knet_dev_t *hDev, int mode)`

Function: sets a command frame to a given khepera3 device.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- mode mode type; should be kMotModeIdle for normal usage.

Return: nothing.

### 6.3.12 kmot\_SetSampleTime

Call: void kmot\_SetSampleTime (knet\_dev\_t \*hDev, int sample)

Function: sets the sample time for the motor control.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- sample time for the motor control (should be 1550 by default).

Return: nothing.

### 6.3.13 kmot\_SetMargin

Call: void kmot\_SetMargin (knet\_dev\_t \*hDev, int margin)

Function: sets the margin for position control.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- margin +/- margin for position (should be 6 by default).

Return: nothing.

### 6.3.14 kmot\_SetOptions

Call: void kmot\_SetOptions (knet\_dev\_t \*hDev, int hwOptions ,  
int swOptions )

Function: sets the options for the motor control.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- hwOptions hardware flag; should be by 0 by default.
- swOptions software; should be (kMotSWOptWindup |kMotSWOptStopMotorBlk) by default.

Return: nothing.

### 6.3.15 kmot\_ResetError

Call: void kmot\_ResetError (knet\_dev\_t \*hDev)

Function: reset the motor.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).

Return: nothing.

### 6.3.16 kmot\_SetBlockedTime

Call: void kmot\_SetBlockedTime (knet\_dev\_t \*hDev, int time)

Function: set the motor blocked time.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- time time before detecting that the motor is blocked; by default: 10.

Return: nothing.

### 6.3.17 kmot\_ConfigurePID

Call: void kmot\_ConfigurePID( knet\_dev\_t \*hDev,int regtype , int16\_t Kp , int16\_t Kd , int16\_t Ki )

Function: configure the motor PID.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- regtype kMotRegSpeed for speed control, kMotRegPos for position control.
- Kp proportional factor (default speed / position : 620 / 600).
- Kd derivative factor (default speed / position : 3 / 20).
- Ki integral factor (default speed / position : 10 / 30).

Return: nothing.

### 6.3.18 kmot\_SetSpeedProfile

Call: void kmot\_SetSpeedProfile(knet\_dev\_t \*hDev,int maxspeed  
,int acceleration )

Function: configure the motor speed profile.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- maxspeed maximum speed to reach.
- acceleration to use.

Return: nothing.

### 6.3.19 kmot\_SetPoint

Call: void kmot\_SetPoint(knet\_dev\_t \*hDev, int regtype , long set-  
Point )

Function: set motor speed or position.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- regtype type of regulation: kMotRegPosProfile for position using profile, kMotRegSpeed for speed.
- setPoint speed or position command to reach.

Return: nothing.

### 6.3.20 kmot\_GetMeasure

Call: long kmot\_GetMeasure(knet\_dev\_t \*hDev, int regtype)

Function: get motor speed or position.

Parameter:

- hDev is a handle to an opened knet socket (Khepera3:dsPic).
- regtype type of position to get: kMotRegPos for position, kMotRegSpeed for speed.

Return: position or speed.



This communication protocol allows complete control of the robot functions through a RS232 serial line. The required configuration is presented in section 4.3. The serial line set-up on your host computer must match the one set on the robot according to the chosen running mode.

The protocol is made of commands and responses, all in standard ASCII codes. A command is sent from the host computer to the robot: it is starting with an upper case character and followed, if necessary, with numerical or literal parameters separated with comma and terminated by a line feed. The response is sent by the robot to the host computer: it is starting with the same character that was initiating the command but using lower case, and followed, if necessary, with numerical or literal parameters separated with comma and terminated by a line feed (`\n`) and a carriage return (`\r`).

When a command ask for a value bigger than 8 bits (bigger than 255) the following prefixes must be added:

- d : for a 16 bits value (smaller than 32768 and bigger or equal than -32768)
- l : for a 32 bits value
- f : for a floating value

Example to set the Speed: `D,l20000,l20000`

To better understand this protocol, please refer to the following simple test:

- Set the connection configuration presented in section 4.3.
- Start a terminal emulator on your host computer with the serial line set to 115200 Baud, 8 bit data, 1 start bit, 1 stop bits, no parity.
- Type the capital letter B followed by a carriage return or a line feed.
- The robot must respond with b followed by an indication of the version of software running on the robot and terminated by a line feed.
- Type the capital letter N followed by a carriage return or a line feed.
- The robot must respond with n followed by 11 numbers separated by a comma and terminated by a line feed. These numbers are the values of the proximity sensors presents on the robots.
- Retry the same command (N) putting some obstacles on the front of the robot. The response must change.
- Try other commands...

## A Start Braitenberg mode

---

Command: A, mode (8 bits)  
 Answer: a  
 Effect: Start the Braitenberg mode with the Infrared sensor (mode = 0) or with the ultrasonic sensor (mode = 1). To stop the Braitenberg mode, send the A,2 command.  
 Syntax: A,0

## B Read software version

---

Command: B  
 Answer: b, version\_of\_BIOS, revision\_of\_BIOS  
 Effect: Give the software version stored in the robot's EEPROM.

## C Configure the current firmware operation

---

Command: C, array\_index(8bits), array\_value(16bits)  
 Answer: c  
 Effect: Configure the actual firmware state. The configuration array is to be seen as a table. Each line in the table means a parameter and a value may be associated with.  
 Syntax: C,0,d3

Index	Default Value	Description:
0	0b00000100	Decide how many US sensor will be active. See the table below for supported configurations.
1	3	Decide the maximum echo numbers.
2	0	Not Used.
3	0	Not used.
4	0xFFFF	IR sensor mask, manage the active IR sensor (bit0 = IR0, bit1 = IR1, etc...).
5	12	IR gain for Braitenberg.
6	1	Upper body mounted. If the upper body isn't mounted, change this value to 0 to get better US measure.

## A. Communication protocol

---

The supported US sensors configuration are listed in the following table.

Mask	Binary	Decimal	Description:
NONE	0b00000000	0	None of the US sensor.
US1ONLY	0b00000001	1	Only the US sensor 1.
US2ONLY	0b00000010	2	Only the US sensor 2.
US3ONLY	0b00000100	4	Only the US sensor 3.
US4ONLY	0b00001000	8	Only the US sensor 4.
US5ONLY	0b00010000	16	Only the US sensor 5.
US1TO2	0b00000011	3	US sensor 1 to 2.
US2TO3	0b00000110	6	US sensor 2 to 3.
US3TO4	0b00001100	12	US sensor 3 to 4.
US4TO5	0b00011000	24	US sensor 4 to 5.
US1TO3	0b00000111	7	US sensor 1 to 3.
US2TO4	0b00001110	14	US sensor 2 to 4.
US3TO5	0b00011100	28	US sensor 3 to 5.
US1TO4	0b00001111	15	US sensor 1 to 4.
US2TO5	0b00011110	30	US sensor 2 to 5.
USALL	0b00011111	31	All US sensors.

## D Set speed

---

Command: D, speed\_motor\_left (32bits), speed\_motor\_right (32bits)  
Answer: d  
Effect: Set the speed of the two motors. See in section 3.2.3 to calculate the equivalent Speed.  
Syntax: D,l20000,l20000

## E Read speed

---

Command: E  
Answer: e, speed\_motor\_left, speed\_motor\_right  
Effect: Read the instantaneous speed of the two motors. See in section 3.2.3 to calculate the equivalent Speed.  
Example: e,20000,20000

## **F Set Target Profile**

---

Command: F, target\_position\_motor\_left (32bits), target\_position\_motor\_right (32bits)  
Answer: f  
Effect: Set a position to be reached. The move will be performed with three phase, a acceleration to reach the maximum speed, a constant speed and a deceleration phase before the finish position. The unit is the pulse, each one corresponds to 0,047 mm with old firmware, 0.031 mm with new firmware (with encoder resolution x4 (default); see section 3.2.3).  
Syntax: F,11000,11000

## **G Get a measure from the US peripheral**

---

Command: G, US\_number (8bits)  
Answer: g, EchoNbr, Dist1, Ampl1,Time1,Dist2,Ampl2, Time2, Dist3, Ampl3, Time3, Dist4, Ampl4, Time4, Dist5, Ampl5, Time5, Noise  
Effect: Retrieve US measures (distance in [cm] and time in [ms]) from a given sensor number. The sensor number is supposed to be 1 to 5.  
Syntax: G,3  
Example: g,1,27,2900,100000,0,0,0,0,0,0,0,0,0,0,0,0,0,0,1800

## **H Configure the PID controler**

---

Command: H, T (16bits), Kp (16bits), Ki (16bits), Kd (16bits)  
Answer: h  
Effect: Set the proportional (Kp), the integral (Ki) and the derivative (Kd) parameters of the T regulator where T can be 0 (speed controler) or 1 (position controler).  
Syntax: H,d1,d200,d5,d10

## **I Set position**

---

Command: I, position\_motor\_left (32bits), position\_motor\_right (32bits)  
Answer: i  
Effect: Set the 32 bit position counter of the two motors. The unit is the pulse, each one corresponds to 0,047 mm with old firmware, 0.031 mm with new firmware (with encoder resolution x4 (default); see section 3.2.3).  
Syntax: I,11000,11000

## **J Configure the speed profile controller**

---

Command: J, max\_speed (16bits), acceleration (8bits)  
Answer: j  
Effect: Set the speed and the acceleration for the trapezoidal speed shape of the position controller. The max\_speed parameter indicates the maximal speed reached during the displacement. See section 3.2.3 for more details. At the reset, these parameters are set to standard values: max\_speed to 20000, acc to 64.  
Syntax: J,d15000,10

## **K Set Programmable Led**

---

Command: K, LED (8bits), State (8bits)  
Answer: k  
Effect: Set the state of the two Programmable Leds ( see section 3.1.3, Led 5 & 6). LED select which one must be set (0 = led 5, 1 = Led 6).  
State select the operation (0 = OFF, 1 = ON, 2 = Change state).  
Syntax: K,0,1

## **L Set speed open loop**

---

Command: L, speed\_motor\_left (32bits), speed\_motor\_right (32bits)  
Answer: l  
Effect: Set the speed of the two motors without a PID controller. Where a value of 1023 correspond to PWM of 100%.  
Syntax: L,1500,1500

## **M Init Motors**

---

Command: M  
Answer: m  
Effect: Initialise or reset the motor controllers. Must be used if an error like motor blocked or current limit occurred

## **N Read proximity sensors**

---

Command: N  
Answer: n,val\_sens\_back\_left, val\_sens\_left\_90, val\_sens\_left\_45,  
val\_sens\_front\_left, val\_sens\_front\_right, val\_sens\_right\_45,  
val\_sens\_right\_90, val\_sens\_back\_right, val\_sens\_back,  
val\_sens\_ground\_right, val\_sens\_ground\_left, time\_stamp  
Effect: Read the 12 bit values of the 11 proximity sensors. The last  
argument is the relative time stamp of the measure in [ms].  
(section 3.3), from the front sensor situated at the left of the  
robot, turning clockwise to the back-left sensor.

## **O Read ambient light sensors**

---

Command: O  
Answer: n,val\_sens\_back\_left, val\_sens\_left\_90, val\_sens\_left\_45,  
val\_sens\_front\_left, val\_sens\_front\_right, val\_sens\_right\_45,  
val\_sens\_right\_90, val\_sens\_back\_right, val\_sens\_back,  
val\_sens\_ground\_right, val\_sens\_ground\_left, time\_stamp  
Effect: Read the 12 bit values of the 11 light sensors (section 3.3.1),  
from the front left sensor turning clockwise to the back-left  
sensor. The last argument is the relative time stamp of the  
measure in [ms].

## **P Set Target Position**

---

Command: P, target\_position\_motor\_left (32bits), tar-  
get\_position\_motor\_right (32bits)  
Answer: p  
Effect: Set a position to be reached. The move will be performed  
without acceleration and deceleration. The unit is the pulse,  
each one corresponds to 0,047 mm with old firmware, 0.031  
mm with new firmware (with encoder resolution x4 (de-  
fault); see section 3.2.3).  
Syntax: P,l1000,l1000

## **Q Reserved**

---

## **R Read position**

---

Command: R  
Answer: r, position\_motor\_left, position\_motor\_right  
Effect: Read the 32 bit position counter of the two motors. The unit is the pulse, each one corresponds to 0,047 mm with old firmware, 0.031 mm with new firmware (with encoder resolution x4 (default); see section 3.2.3).

## **S Reserved**

---

## **T Reserved**

---

## **U Enter the serial boot loader mode**

---

Command: U  
Answer: u  
Effect: Switch to the firmware upgrade mode. Be careful, not to upload a bad hex file into the dsPic memory space. If the dsPic memory is corrupted, an external programmer will be required to reflash the memory.  
Do not turn off or reset the KheperaIII when the uploader mode running. This will corrupt the dsPic memory. If you have run the mode by mistake, wait until the timeout occurs (5-7 seconds).

## **V Get Battery State**

---

Command: V  
Answer: v, battery\_measure\_unit, battery\_measure\_decimal  
Effect: 0: Read the voltage of the battery (Units: 1V , 0.1mV) .  
1: Read the current of the battery (Units: 1A, 0.1mA).  
2: Read the battery Average Current (Units: 1A, 0.1mA).  
3: Read the battery Absolute Remaining Capacity (Units: 1mAh).  
4: Read the Temperature of the battery (Units: 1 C, 0.1 C).  
5: Read the battery Relative Remaining Capacity (Units: %).

## **W Reserved**

---

## **X Binary read**

---

Command: X

Answer: 65 bytes: 1 byte 'x' char, 22 bytes proximity sensor, 22 bytes proximity ambient light sensor, 8 bytes motor speed, 8 bytes motor position, 4 bytes time stamp, 1 byte line feed (\n), 1 byte carriage return (\r)

Effect: read sensors in binary mode

## **Y Unused**

---

## **Z Zero the relative time stamp**

---

Command: Z

Answer: z

Effect: Reset the relative time counter.

## B WARRANTY

---



K-TEAM warrants that the Khepera III is free from defects in materials and workmanship and in conformity with the respective specifications of the product for the minimal legal duration, respectively one year from the date of delivery.

Upon discovery of a defect in materials, workmanship or failure to meet the specifications in the Product during the afore mentioned period, Customer must request help on K-Team Internet forum on (<http://www.k-team.com/forum/>) by detailing:

- the version of the Khepera III
- the programming environment of the Korebot II if mounted (standard, version, OS)
- the standard use of Product before the appearance of the problem
- the description of the problem.

If no answers have been received within two working days, Customer can contact K-TEAM support by phone or by electronic mail with the full reference of its order and Korebot II serial number.

K-TEAM shall then, at K-TEAM's sole discretion, either repair such Product or replace it with the equivalent product without charging any technical labor fee and repair parts cost to Customer, on the condition that Customer brings such Product to K-TEAM within the period mentioned before. In case of repair or replacement, K-TEAM may own all the parts removed from the defective Product. K-TEAM may use new and/or reconditioned parts made by various manufacturers in performing warranty repairs and replacement of the Product. Even if K-TEAM repairs or replaces the Product, its original warranty term is not extended.

This limited warranty is invalid if the factory-applied serial number has been altered or removed from the Product.

This limited warranty covers only the hardware and software components contained in the Product. It does not cover technical assistance for hardware or software usage and it does not cover any software products contained in the Product. K-TEAM excludes all warranties expressed or implied in respect of any additional software provided with Product and

## B. Warranty

---

any such software is provided "AS IS" unless expressly provided for in any enclosed software limited warranty. Please refer to the End User License Agreements included with the Product for your rights with regard to the licensor or supplier of the software parts of the Product and the parties' respective obligations with respect to the software.

This limited warranty is non-transferable.

It is likely that the contents of Customer's flash memory will be lost or reformatted in the course of the service and K-TEAM will not be responsible for any damage to or loss of any programs, data or other information stored on any media or any part of the Product serviced hereunder or damage or loss arising from the Product not being available for use before, during or after the period of service provided or any indirect or consequential damages resulting therefore.

IF DURING THE REPAIR OF THE PRODUCT THE CONTENTS OF THE FLASH MEMORY ARE ALTERED, DELETED, OR IN ANY WAY MODIFIED, K-TEAM IS NOT RESPONSIBLE WHATEVER. CUSTOMER'S PRODUCT WILL BE RETURNED TO CUSTOMER CONFIGURED AS ORIGINALLY PURCHASED (SUBJECT TO AVAILABILITY OF SOFTWARE).

Be sure to remove all third parties' hardware, software, features, parts, options, alterations, and attachments not warranted by K-TEAM prior to Product service. K-TEAM is not responsible for any loss or damage to these items.

This warranty is limited as set out herein and does not cover, any consumable items (such as batteries) supplied with the Product; any accessory products which is not contained in the Product; cosmetic damages; damage or loss to any software programs, data, or removable storage media; or damage due to (1) acts of God, accident, misuse, abuse, negligence, commercial use or modifications of the Product; (2) improper operation or maintenance of the Product; (3) connection to improper voltage supply; or (4) attempted repair by any party other than a K-TEAM authorized module service facility.

This limited warranty does not apply when the malfunction results from the use of the Product in conjunction with any accessories, products or ancillary or peripheral equipment, or where it is determined by K-Team that there is no fault with the Product itself.

K-TEAM EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES THAN STATED HEREINBEFORE, EXPRESSED OR IMPLIED, INCLUDING

## B. Warranty

---

WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE TO THE FULLEST EXTENT PERMITTED BY LAW.

Limitation of Liability: IN NO EVENT SHALL EITHER PARTY BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM PERFORMANCE OR FAILURE TO PERFORM UNDER THE CONTRACT, OR FROM THE FURNISHING, PERFORMANCE OR USE OF ANY GOODS OR SERVICE SOLD OR PROVIDED PURSUANT HERETO, WHETHER DUE TO A BREACH OF CONTRACT, BREACH OF WARRANTY, NEGLIGENCE, OR OTHERWISE. SAVE THAT NOTHING HEREIN SHALL LIMIT EITHER PARTY'S LIABILITY FOR DEATH OR PERSONAL INJURY ARISING FROM ITS NEGLIGENCE, NEITHER PARTY SHALL HAVE ANY LIABILITY TO THE OTHER FOR INDIRECT OR PUNITIVE DAMAGES OR FOR ANY CLAIM BY ANY THIRD PARTY EXCEPT AS EXPRESSLY PROVIDED HEREIN.